

## PTO Installation Alternative

In addition to the current method of PTO installation from beneath the vehicle, an alternative method has been developed that allows the installation from above by removing the PTO patch panel in the floor. The instructions are as follows.

1. Remove the rear package tray located behind the seat from the vehicle.



2. Unbolt the seat and move it to the rear of the cabin where the package tray was removed.
3. Remove the sill guards (rocker panel covers) passenger side to allow the vinyl floor mat to be lifted. They are removed by prying straight up to disengage metal clips.



4. Lift the floor mat and fold it rearward and toward the drivers side to expose the patch panel



5. Remove the fasteners and sealer from around the patch panel. Cut away the sound deadener pad to expose the transmission PTO access.



6. You are now able to install and assemble the PTO and pump through the opening. Note: larger pumps must be inserted through the hole and moved toward the rear of the opening before installing the PTO. The pump is then slid forward to connect to the installed PTO.

7. To assemble, reverse the above procedure using RTV to reseal the PTO floor pan patch panel.