#### **Speaker Installation**

Rear speakers can be added to the ProMaster. There are different requirements for adding rear speakers depending on the radio that the vehicle is equipped with. Sales code BC3 (up fitter interface connector) is required regardless of the radio. It provides a way to connect the speakers to the electrical system. The up fitter connectors can be found at the base of the passenger side B pillar behind a trim panel. See ProMaster BBG "UPFITTERS RADIO CONNECTOR" document under the "ELECTRICAL/WIRING INFORMATION" heading for more detail regarding the connections.

#### Standard AM, FM, MP3 Radio - RH3

ProMaster vans equipped with the RH3 radio are shipped from the factory with the fader control set to full front as the vehicle does not come equipped with rear speakers. If the fade is set to the rear with no rear speakers connected, little to no sound would be heard. To add rear speakers to vehicles with this radio option, connect the speakers to the vehicle's electrical system and shift the fade setting more towards the rear until the desired front/rear bias is achieved.

#### Optional AM, FM, CD, UConnect, Blue Tooth, Touch Screen Radio - RA2

ProMaster vans equipped with the RA2 radio are shipped from the factory with the rear speakers turned off as the vehicle does not come equipped with rear speakers. If the speakers were turned on with no speakers connected, diagnostic routines in the radio would set rear speaker faults. To add rear speakers to a vehicle with RA2, the vehicle must have been built with sales code RED (rear speaker prep) RED will ensure proper configuration of the vehicle electronics that will allow the speaker outputs to be enabeled. RED is packaged with BC3. You cannot order RED without BC3.

If rear speakers are added, they must be enabled by accessing the car layout screen in alternate engineering menu in the radio.

- NOTE: To eliminate the setting of fault codes, rear speakers should only be enabled AFTER the rear speakers have been properly connected to the vehicle electrical system.
- NOTE: Do not attempt to make any other changes to radio configurations while in the alternate engineering menu.

After the speakers are properly connected, perform the steps outlined on the following pages to enable the speakers. Once the steps are correctly performed, the speaker fade control will now be visible in the audio control menu of the radio and the rear speakers will function.


1. Press the **RADIO** and **MEDIA** buttons then, shortly after that, while still holding **RADIO** and **MEDIA**, press the **BROWSE/ENTER** button. Hold all for approximately 5 seconds. The following screens will appear.



2. After approximately 5 seconds. The following screen will automatically appear.



3. Touch the UP and DOWN arrow soft buttons on the screen to locate the line for AUD Eng Menu



4. Touch the line for **AUD Eng Menu**. The following screen will appear.



5. Touch the line for CARLAYOUT: 6(0x06). The following screen will appear.



6. Touch the line for **+1** or **-1** to scroll through the different layouts until the desired layout appears in the top line. For enabling rear speakers, select 8(0x08).

CarLayout: 6(0x06) → Front Speakers Only 8(0x08) → Front and Rear Speakers

NOTE: Layouts other than the one listed above will also appear. They are invalid. Only select one of the two layouts listed above.

The following screen will appear.



7. Touch the UP and DOWN arrow soft buttons on the screen to locate the lines for OK and CANCEL.



8. Confirm the selection by touching the line for **OK**. The following screen will appear.



9. Exit the **AUD** screen by touching the small **UP ARROW** button on the **LEFT** of the menu. The following screen will appear.



10. Exit the **Engineering Mode** menu by pressing the **RADIO** and **MEDIA** buttons then, shortly after that, while still holding **RADIO** and **MEDIA**, press the **BROWSE/ENTER** button. Hold all for approximately 5 seconds. The normal Radio or SXM tuning screen will appear.



- 11. Switch off the radio, turn the ignition key off and remove it from the ignition, disconnect any service tools from the diagnostic connector and close all doors. Wait 5 minutes to allow all vehicle electronics to power down internally.
- 12. Turn the ignition key on and turn on the radio. Rear speakers should now be enabled. Verify by accessing the balance/fade screen. If the rear speakers have been enabled, the following screen will appear and the rear speakers will be active.



NOTE: Should you desire to remove the rear speakers at a later time, you can repeat the steps listed in this section except that you will select 6(0x06) in step 6.