

PTO GENERAL GUIDELINES

- The Ram 3500/4500/5500 Chassis cab models equipped with gas and diesel engines that have the PTO prep option (LBN or LBV) have the capability of mounting and controlling a PTO.
- The Aisin AS69RC automatic transmission can use devices up to 60HP and 250 ft lbs torque. While the model, the number, and HP/torque capability of the transmission have increased, the Chelsea 270 and Muncie CS6 models continue to mount to the right side of the transmission as in previous years.
- The G56 manual transmissions are limited in power output only by the PTO manufacturers' maximums. Chelsea 442 (deep mount) series fit this transmission, however on 4x4 models this PTO is very close to the front driveshaft. Muncie Alpha series fits this transmission.
- For 2013 and later a left hand side PTO (option code LBV) will be available as a factory option on 4x2 chassis cab models. This should allow for easier PTO installation on 4x2 models and allow for the shaft driven applications. In this position, Muncie model FA6B is the only PTO that fits.

Pump sizes

- The automatic transmission models have been test fit with 19 GPM rated single pumps and tandem 13GPM rated pumps. While these larger pumps have limited clearance to the exhaust system and it has been mentioned as a concern, it should be noted that the diesel exhaust in the PTO area is a double wall pipe which provides significant insulation. In fact, in our testing in over 100 degree Fahrenheit ambient temperatures we never exceeded 200 degrees F on the PTO pump or hoses. The gasoline models have larger clearance envelopes than the diesels. However, the higher heat rejection of the gasoline engine exhaust system requires special care to ensure the PTO pump system is protected.
- The manual transmission models are as follows: The 4x2 models have no particular packaging limitations with respect to direct mount pumps. The 4x4 models are limited by the location of the front driveshaft to approximately a standard 11 GPM rated pump (although larger pumps may have been successfully fitted in the field). However, some customers have had success using bent axis piston pumps (mounted forward) to get substantially higher flows.
- If you have specific PTO and pump fitment questions and can provide the actual PTO and pump combination, we can test fit it and provide pictures and instructions on how to install your specific combination.

NOTE: Never remove heat shields provided as original equipment. It is also the Final Stage Manufacturers responsibility to install appropriate shielding to any secondary body or equipment installed onto the Chassis Cab. Final Stage / Individual Manufacturers assume all responsibility related to modifications performed.

PTO Limitations

Please read this information carefully and call us with any questions before you order a vehicle so you understand the specific capabilities of our PTO system.

- The Automatic transmission PTO is turbine driven not engine driven. What this means is that the PTO will work only with the stationary mode in park, or in mobile mode with the vehicle moving at approximately 7 mph and above or in neutral. Because of this the PTO system is not a suitable system for vehicles like: snow plows, autoloader wreckers, or dump trucks if they are used to dump and spread at a crawling speed. These vehicles are more effective with an engine driven 'clutch pump' type hydraulic pump. Alternatively, Parker-Chelsea makes a product called Stored Energy Management System (SEMS) that allows such applications to function.

PTO Operation

The 3500/4500/5500 Ram Chassis Cab vehicle, when equipped with either the automatic Aisin 6spd or manual G-56 6spd transmissions, will allow for an aftermarket upfit with a transmission driven PTO (power take off). The customer will have the ability to operate the PTO in either a “stationary” or “mobile” mode. Under normal operation the vehicle will go to a 900 rpm when PTO is engaged. By utilizing the cruise switches the idle speed can then be adjusted to between 900 and 2000 rpm’s.

NOTE: Due to emission requirements the gasoline engine PTO may have delay in engagement. It may require up to ten seconds for the PTO to engage.

Stationary Mode

This feature interacts with the transmission to utilize an auxiliary PTO to drive equipment. Activated by a switch inside the cab, this feature operates only when the vehicle is stationary.

Once active, the engine speed increased by holding the RES ACCEL button on the steering wheel or decreased by holding the COAST button. On the gasoline engine vehicle you must turn on the cruise control switch to enter this variable speed mode.

This is the factory programmed setting. If you need a single set speed, you will now be able to program it (and disable the cruise switches) via the Electronic Vehicle Information Center (EVIC) screen in the center of the cluster.

Stationary PTO is available only when the vehicle is stationary. When the truck is equipped with an automatic transmission, it must be in Park and the service brake must be released and functional. When the truck is equipped with a manual transmission, the Parking Brake must be Set and the service brake must be released and functional

To operate the PTO in this mode the vehicle must meet the following conditions:

- Be in “park” position (vehicles equipped with automatic transmission)
- PTO switch has been activated
- Parking brake applied (vehicles equipped with manual transmission)
- Clutch not depressed (clutch interlock switch)
- Vehicle must be running
- No transmission, engine, accelerator, brake or clutch switch faults present
- PTO must be correctly installed using the vehicle provided circuits

To operate the PTO via a remote switch the customer must make sure the above conditions are met. It is vital for proper operation that the PTO and remote have been installed correctly paying special attention to ensure the vehicle provided wiring has been connected properly. This is the responsibility of the installer of the PTO and switches/remote system. It is the responsibility of the PTO manufacturer to ensure that their electrical (switches and remote) system is compatible with the vehicle’s electrical architecture and software functionality.

Mobile Mode

Mobile mode allows for use of the PTO when the vehicle is in motion. This feature, when activated by the menu available on the Electronic Vehicle Information Center (EVIC) screen in the center of the cluster, will allow you to enter mobile PTO mode when you press the PTO switch on the dash.

When this feature is selected stationary PTO and Remote PTO features are not available.

Chassis Cab PTO Operation & Installation Guide

To operate the PTO in this mode the vehicle must meet the following conditions:

- PTO switch has been activated
- Vehicle must be in “park” position (vehicles equipped with automatic transmission)
- Parking brake must not be applied
- Clutch not depressed (clutch interlock switch)
- No transmission, engine, accelerator, brake or clutch switch faults present
- Vehicle must be running
- PTO must be correctly installed using the vehicle provided circuits

The customer may choose to use the PTO while the vehicle is moving. To do so the PTO function must be activated prior to taking the vehicle out of “park”. This is accomplished by activating the PTO on/off switch. At this point the customer may place the vehicle in a forward or reverse gear and have PTO operation.

The PTO will also function in park and neutral but without an increase in idle speed. However, the accelerator pedal can be used to increase PTO speed. Mobile mode does not provide the exact same capability as a ‘live drive’ i.e. you cannot have PTO capability at zero vehicle speed in drive. However some customers have had success with shifting the vehicle into neutral and allowing the vehicle to coast.

To disengage PTO operation and return to “standard vehicle operation” simply turn the PTO on/off switch to the off position.

Remote Mode Features

Remote mode allows the use of an aftermarket auxiliary switch to actuate the PTO. Presumably this will be from a location other than the cab of the truck, or some automated/relay driven method to turn on the PTO is required.

Remote PTO can be calibrated for one to three selectable engine speeds.

Remote mode also is the only method that accommodates multiple PTO speeds. Up to three different PTO speeds can be programmed. These speeds are programmed via the Electronic Vehicle Information Center (EVIC) screen in the center of the cluster (see page 2). The circuits that enable these multiple speeds are contained in the Vehicle System Interface Module (VSIM). The VSIM module is located under the dash on the driver’s side. The connecting wires are contained in the upfitter wiring kit and VSIM wiring kit. [Click here for VSIM section.](#)

Remote PTO feature has a higher priority than Idle Up. If the Remote PTO feature is active the Idle Up switches are ineffective. The Idle Up or Stationary PTO feature cannot be activated until the Remote PTO relinquishes control

To operate the PTO in this mode the vehicle must meet the following conditions:

- Be in “park” position (vehicles equipped with automatic transmission)
- Upfitter provider (on/off) switch has been activated
- Parking brake applied (vehicles equipped with manual transmission)
- Clutch not depressed (clutch interlock switch)
- Vehicle must be running
- No transmission, engine, accelerator, brake or clutch switch faults present
- PTO must be correctly installed using the vehicle provided circuits

Various features provided by the Cummins / Chrysler module

Remote Throttle and Remote Throttle Switch

This feature allows the use of a 0-10K or 0-100K potentiometer to function as a remote throttle. By connecting the circuits K400, F856, and K128 to the each end and the movable center leg respectively, the potentiometer will function as a remote throttle. These circuits are located on a connector on the driver's side of the transmission bellhousing area. The wiring and for this and two functions below as well as schematics are contained in the upfitters wiring kit delivered with every vehicle. Circuit K129 must be connected to circuit V937 to turn on this feature.

Note: Remote throttle automatically disables the accelerator

Note: These features must be enabled by the dealer on 2013 and early 2014 trucks

Accelerator interlock

This allows the accelerator to be locked out when activated. This feature is often used in conjunction with remote PTO or remote throttle. While active it disables the vehicles accelerator pedal typically for safety reasons. This feature is activated by connecting circuit K 810 to V937. Diesel only.

Switch Return

Electrical return/ground for switch circuits.

I1939 Interface (Cummins only)

Cummins provides this interface to "gate" certain CAN messages for customer use. It is an industry standard three way connector located underhood, on the driver's side of the engine near the connection to the intake manifold. Messages included are vehicle speed, engine speed, park brake on/off, system voltage – filtered, brake switch status, clutch switch engaged, wait to start lamp status and coolant temp.

NOTE: On gasoline engine models, for remote throttle to function, PTO and accelerator must be activated.

PTO Circuit Definition Chart

Location E Transmission Bellhousing Drivers Side (Cummins)

Transmission Bellhousing Body Passenger Side (Gasoline)

The following chart is provided to assist in correctly interfacing the PTO with the vehicle:

Circuit Name	Type/Gauge/Color	Circuit Functionality	Description	Usage
F856	18T - YL/PK	5V engine sensor feed	5 volt pwr supply to the remote potentiometer (remote's control power circuit). Supplied by the engine controller	Remote throttle control
K400	18T - BR/VT	accel pedal position sensor	Remote's ground (ground to the potentiometer of remote). Supplied by the engine controller. Do not hook to other grounding location	Remote throttle control
K128	18T - DB/LG	remote throttle signal	Remote signal sent to the engine controller. Signal from the remote's potentiometer.	Remote throttle control
K129	18T - DB	remote throttle switch	On/Off switch provided by customer to "turn on/off remote function. Remote switch closes to ground.	Remote throttle control
K119	18T - LG/BK	maximum operating speed switch	Feature selects a lower maximum engine speed when switch is "on". Switch closes to ground. Customer supplied switch.	Max operating speed switch
K810	18T - VT/DG	Accelerator interlock switch	Disable accelerator control of engine by closing an operator installed switch. This switch closes to ground.	Customer supplied switch
F425	18T - PK	Remote PTO Switch	Customer supplied remote PTO on/off switch. Switch closes to ground.	Remote PTO
V937	18T - VT/BR	Non-Functional for 2013	Ground for 2014	Signal Return